

ITEM NO.	DESCRIPTION	MAN.P/NO.	D&S P/NO.
1	Discharge, 8-25 Stages	050100RP	DS2-1A
1	Discharge, 33-60 Stages	0050100LORP	DS2-1B
2	Valve Casing	0050200	DS2-2
3	Valve guide	0050300	NSI
4	Valve cone	0050400	NSI
12	Diffuser - 8-25 Stages	0251200	DS5-12A
12	Diffuser - 33-60 Stages	0251200L0	DS5-12B
18	Impeller	0251800	DS5-18
24	Stop Ring	0052400	DS2-24
26	Spacing washer for stop ring	0052600	DS2-26
34	Strainer - 8-25 Stages	0183400	DS3-34A
34	Strainer -33-60 Stages	0183400L0	DS3-34B
36	Suction Interconnector - 8-25	0053600	DS2-36A
36	Suction Interconnector -33-60	0403600	DS2-36B
40	Pump shaft/Coupling - 8 Stage	005370008	DS5-40A
40	Pump shaft/Coupling -12 Stage	005370012	DS5-40B
40	Pump shaft/Coupling -17 Stage	005370017	DS5-40B
40	Pump shaft/Coupling - 25 Stage	005370025	DS5-40D
40	Pump shaft/Coupling - 33 Stage	005370033	DS2-40D
40	Pump shaft/Coupling - 44 Stage	005370044	DS5-40D
40	Pump shaft/Coupling - 60 Stage	005370060	DS5-40F
42	Shaft sleeve	0054200	DS2-42A
47	Strap - 8 Stage	005470008	NSI

NSI - Non stock item available on special order only

ITEM NO.	DESCRIPTION	MAN.P/NO.	D&S P/NO.
47	Strap - 12 Stage	005470012	NSI
47	Strap - 17 Stage	005470017	NSI
47	Strap - 25 Stage	005470025	NSI
47	Strap - 33 Stage	005470033	DS2-47A
47	Strap - 44 Stage	005470044	NSI
47	Strap - 60 Stage	005470060	NSI
52	Cable guard - 8 Stage	005520008	NSI
52	Cable guard - 12 Stage	005520012	NSI
52	Cable guard - 17 Stage	005520017	NSI
52	Cable guard - 25 Stage	005520025	NSI
52	Cable guard - 33 Stage	005520033	NSI
52	Cable guard - 44 Stage	005520044	NSI
52	Cable guard - 60Stage	005520060	NSI
86	Valve seat	0058600	DS2-86
87	Neck ring	0058700	DS2-87
88	Nut M8	J04M08	NSI
89	Bearing	0058900	DS2-89
90	Screw M8	J02M0830	NSI
91	Washer	0059100	NSI
93	Lock nut	0059300	NSI

NSI - Non stock item available on special order only

